
## 🖢 🛐 💿 🕖 🔡 sensafe 🛅 ITSsensafe

## **INDUSTRIAL TEST SYSTEMS, INC.**

## **COMBINED/TOTAL CHLORINE TEST**



Tap '**SELECT** Test' at the top. Tap Chorine, Free (DPD-1) CL. The iDip and app will both display Free Chlorine.



Remove one eXact® Strip Micro CL (DPD-1), 486637 and set in a dry, convenient place.




Rinse the cell 3 times with the water sample to be tested and FILL to the top to begin test.






Press (ERO/OI) and the iDip<sup>®</sup> display reads  $O_{PPM}$  indicating the meter is ready to test.



Press **(BEAD)** to initiate a 20 second countdown and simultaneously **DIP** the test strip by submerging all pads in the sample then use a gentle constant back and forth motion (2 strokes per second) until the timer displays "1". Remove and discard the strip. **READ** result displayed as Free Chlorine. DO NOT empty CELL, continue to step 10 to get result as Combined Chlorine.



Tap '**SELECT** Test' at the top. Tap Chorine, Combined (DPD-3) CL. The iDip and app will both display Combined Chlorine.





Press (EROID) and the iDip  $^{\otimes}$  display reads  $\mathsf{O}_{\mathsf{PPM}}$  indicating the meter is ready to test.





Remove one  $\textbf{eXact}^{\circledast}$  Strip Micro CL (DPD-3) and set in a dry, convenient place.





Press (BEAD) to initiate a 20 second countdown and simultaneously **DIP** the test strip by submerging all pads in the sample then use a gentle constant back and forth motion (2 strokes per second) until the timer displays "1". Remove and discard the strip.





**READ** result displayed on the iDip<sup>®</sup> and in the app. To save your results and make available for emailing, continue on page 11 of your manual. For results as Total Chlorine, add the Free Chlorine and Combined Chlorine values together (e.g. 1.64 + 0.36 = 2.00 ppm). After testing is complete, rinse CELL immediately.

